

# **Pro 1050**

**SKU:** 460230

#### **FEATURES**

- Industry's first FCC & carrier approved "inline" cellular booster system
- Consists of "main" booster and "inline" booster
- "Inline" booster installed deep inside building and compensates for signal loss in long cable runs to inside antennas
- XDR technology: never shuts down due to overload, even with very strong outside cellular signals
- Automatically compensates for signal loss in up to 300' of cable
- Compatible with all North America cellular networks
- Three year warranty
- Up to +15 dBm downlink power at indoor antenna port, for maximum indoor coverage area



#### **INLINE BOOSTER:**



### Kit Includes



WilsonPro 1050 Two-Part Booster System



Wide Band Directional Antenna + 75' Wilson 400 Cable



Dome Antenna + 100' Wilson 400 Cable



Lightning Surge Protector



100' Wilson 400 Cable



2' Wilson 400 Cable

# **About**

The **WilsonPro 1050** passive distributed antenna system is the first FCC and carrier-approved "in-line" booster solution, providing reliable cell coverage deep inside hard-to-reach areas of buildings, such as equipment rooms, and lower floors of highrise buildings. The system consists of two units: a main amplifier and an inline amplifier, located up to 300' from the main booster. The inline booster compensates for signal loss up to 300' of Wilson400 cable.

The WilsonPro 1050 system amplifies weak cell signals to provide reliable voice and data coverage—including 4G to inside spaces where signals may not penetrate. With new eXtended Dynamic Range (XDR) technology, the amplifier never shuts off due to a strong outside signal or changes in outside signals.

Like all WilsonPro cellular signal boosters, the WilsonPro 1050 features cell site protections that auto-detect and prevent any cell tower interference.

# **Specifications**

MODEL NUMBER	460230			
FREQUENCIES	Band 12	700 MHz		
	Band 13	700 MHz		
	Band 5	850 MHz		
	Band 4	1700/2100 MHz		
	Band 25/2	1900 MHz		
MAX GAIN	70 dB			
IMPEDANCE	50 Ohm			
POWER	110 - 240 V AC, 50 - 60 Hz, 30 W			
CONNECTORS	N-Female			
BOOSTER DIMENSIONS	3.75 x 11.5 x 18 in			
BOOSTER WEIGHT	TBD lbs			




## **Detailed Specifications**

	Pro 1050							
Model Number	460030							
FCC ID	PW0460030 / PW00460030IL							
IC ID	4726A-460030							
Connectors	N-Female							
Antenna Impedance	50 Ohms							
Frequency	698-716 MHz, 729-746 MHz, 746-756 MHz, 777-787 MHz, 824-894 MHz, 1850-1995 MHz, 1710-1755/2110-2155 MHz							
Power output for single cell phone (Uplink) dBm	700MHz Band12/17	700MHz Band13	800MHz	1700MHz	1900MHz			
	24.7	24.7	24.4	25.1	24.5			
Power output for single cell phone (Downlink) dBm	700MHz Band12/17	700MHz Band13	800MHz	2100MHz	1900MHz			
	14.8	14.3	15.6	15	15.1			
	1050 Main			1050 In-Line				
Noise Figure	5 dB nominal			5 dB nominal				
Isolation	> 90 dB			> 90 dB				
Power Requirements	110-220V AC			5V 3A				

The term "IC" before the radio certification number only signifies that Industry Canada technical specifications were met.

Each Signal Booster is individually tested and factory set to ensure FCC compliance. The Signal Booster cannot be adjusted without factory reprogramming or disabling the hardware. The Signal Booster will amplify, but not alter incoming and outgoing signals in order to increase coverage of authorized frequency bands only. If the Signal Booster is not in use for five minutes, it will reduce gain until a signal is detected. If a detected signal is too high in a frequency band, or if the Signal Booster detects an oscillation, the Signal Booster will automatically turn the power off on that band. For a detected oscillation the Signal Booster will automatically turn the power off on that band. For a detected oscillation the Signal Booster will automatically rearm normal operation after a minimum of 1 minute. After 5 (five) such automatic restarts, any problematic bands are permanently shut off until the Signal Booster has been manually restarted by momentarily removing power from the Signal Booster. Noise power, gain, and linearity are maintained by the Signal Booster's microprocessor.

# **Install Diagram**



# Support





**UPC** 

